Backflow Device Installations

- 1. A design data sheet with plans showing the method of protection must be submitted to the North Brookfield Water Department.
- 2. All design data sheets must be reviewed by the Cross Connection Program Coordinator and a certified cross connection surveyor prior to the installation of any backflow prevention device.
- 3. Design Data Sheet Approval Letter or Installation Deficiency letter will follow
- 4. Must have copy of plumbing permit/fire department approval before installation
- 5. Inspection of installation by the North Brookfield Water Department
- 6. Testing of backflow device by certified cross connection tester within 14 days of installation.
- 7. Copy of test results must be forwarded to the North Brookfield Water Dept.